

Rugged xCase for iPad Compatibility Chart

- Full Compatibility - Complete fit and function
- Partial Compatibility - Complete fit with partial function
- Not Compatible

iPad Model	Release Date	iPad Description	Model	Fitment notes
9.7	2010	iPad	A1219 A1337	xCase is not compatible with this model
	2011	iPad 2	A1395 A1396 A1397	xCase is not compatible with this model
	Early 2012	iPad 3rd Gen	A1416 A1403 A1430	xCase is not compatible with this model
	Late 2012	iPad 4th Gen	A1458 A4159 A4160	xCase is not compatible with this model
	Late '13 Early '14	iPad Air	A1474 A1475 A1476	Volume Buttons: placement shifted. Silence Switch: No cutout
	Late 2014	iPad Air 2	A1566 A1567	Camera: Off center. May be obstructed Microphone: Relocated to camera opening
	2016	iPad Pro 9.7"	A1673 A1674 A1675	Camera: Off center, blocks flash Microphone: Relocated to camera opening Speaker: Blocked
	2017	iPad 5th Gen	A1822 A1823	Rugged xCase designed for this model
	2018	iPad 6th Gen	A1893 A1954	Rugged xCase designed for this model
10.5	2017	iPad Pro 10.5"	A1701 A1709 A1852	Rugged xCase designed for this model
	2019	iPad Air 10.5" 3rd Gen	A2152 A2123 A2153 A2154	Rugged xCase designed for this model
11	2018	iPad Pro 11"	A1980 A2013 A1934 A1979	xCase is not compatible with this model
12.9	2015	iPad Pro 12.9"	A1584 A1652	xCase is not compatible with this model
	2017	iPad Pro 12.9" 2nd Gen	A1670 A1671 A1821	xCase is not compatible with this model
	2018	iPad Pro 12.9" 3rd Gen	A1876 A2014 A1895 A1983	xCase is not compatible with this model